

Printing

Marks or fingerprints in the coating.

Cause	Prevention
Coating film marking after being packed and transported too soon.	Allow coating to dry for the time indicated on the product data sheet, before packing and transporting. Choose a more suitable thinner which will enable the coating to dry quicker which will enable the product to be packed sooner. Force dry the coating system before packing and transporting. If two component coating system has been used ensure that the coating has been mixed correctly.